

Plate flat
Teller flach
Assiette plate
Plato llano
Piatto piano
Тарелка плоская
Talíř mělký

PRE 2115	Diameter: 15 cm	6 2/8 inch	Weight: 170 g
PRE 2120	Diameter: 20 cm	7 7/8 inch	Weight: 310 g
PRE 2124	Diameter: 24 cm	9 3/8 inch	Weight: 520 g
PRE 2127	Diameter: 27 cm	10 5/8 inch	Weight: 680 g
PRE 2131	Diameter: 31 cm	12 1/8 inch	Weight: 930 g




Plate deep
Teller tief
Assiette creuse
Plato hondo
Piatto fondo
Тарелка глубокая
Talíř hluboký

PRE 1922	Diameter: 22 cm	8 5/8 inch	Weight: 420 g
----------	-----------------	------------	---------------



Cream soup cup
Suppen Obertasse
Tasse à consommé
Taza consomé
Tazza da brodo
Чашка
Šálek na polévku


Saucer
Untertasse
Soucoupe
Platillo
Sottotazza
Блюдце
Podšálek

PRE 1125	Diameter: 25 cm	9 7/8 inch	Weight: 210 g
----------	-----------------	------------	---------------



Creamer
Giesser
Crémier
Cremera
Cattiera
Молочная бутылка
Mlékovka

PRE 3604	4 cl		Weight: 50 g
----------	------	--	--------------



Cup
Obertasse
Tasse
Taza
Tazza
Чашка
Šálek

Saucer
Untertasse
Soucoupe
Platillo
Sottotazza
Блюдце
Podšálek

PRE 0212	12 cl		Weight: 115 g
----------	-------	--	---------------



Cup
Obertasse
Tasse
Toza
Tazza
Чашка
Šálek

Saucer
Untertasse
Soucoupe
Platillo
Sottotazza
Блюдце
Podšálek

PRE 0219
PRE 0222
PRE 0030

19 cl
22 cl
30 cl

Weight: 170 g
Weight: 200 g
Weight: 220 g

